



| No. | PARTS NAME | No. | PARTS NAME | No. | PARTS NAME | No. | PARTS NAME | No. | PARTS NAME |
|-----|----------------------|------|--------------------------|------|----------------------------|------|-------------------------------|------|-------------------------|
| 43 | Drive shaft washer | 647 | Set plate nail | 1328 | Reel foot spacer | 1551 | Lever wind bushing | 1634 | Friction spring |
| 46 | Reel foot screws | 660 | Bearing ring | 1374 | Handle knob screw 2 | 1552 | Transition tooth fixing screw | 1635 | Frame |
| 185 | M2.5 "E" washer | 661 | Handle washer | 1390 | Drive gear-high speed | 1554 | Spool ring | 1636 | Sideplate(rear) |
| 207 | Push slice screw | 666 | Small ring | 1441 | Drive shaft | 1589 | Reel foot | 1637 | Cover |
| 211 | Set plate screws | 668 | Side plate screws1 | 1447 | Pin with small teeth | 1590 | Handle lock ring | 1638 | Decorative piece |
| 215 | Cover screw | 669 | Side plate screws2 | 1449 | Fixed plate pin | 1591 | Drag tension knob | 1639 | Lever wind shaft |
| 380 | Ball bearing (S605) | 670 | Close cover screws | 1452 | High speed pinion gear | 1593 | Pre-program plate | 1641 | Wire loop |
| 384 | Ball bearing (S6700) | 671 | Spool shaft screw | 1454 | Guide claw nut | 1594 | Pre-program key | 1642 | Handle arm |
| 388 | Ball bearing (S85) | 673 | Screw for bearing cover | 1462 | Drive gear for lever wind | 1600 | Drive shield | 1643 | Spool shaft |
| 389 | Ball bearing (S695) | 680 | Drive shaft coat washer | 1463 | Transitional large gear_P2 | 1602 | Handle shaft coat | 1644 | Double helix lever wind |
| 395 | One-way bearing | 699 | Set plate | 1464 | Transitional gear_P2 | 1606 | Sound coat | 1646 | Slider |
| 400 | Drive shaft coat | 745 | Transitional gear washer | 1467 | Guide claw | 1607 | Transitional large gear_P3 | 1647 | Spool cannulation |
| 401 | "O" ring | 754 | Fixed screw | 1474 | Ceramic ring | 1608 | Transitional gear_P3 | 1648 | Front drag plate |
| 420 | Sound nail | 772 | Handle bolt | 1543 | Ball bearing(S74) | 1613 | Pronunciation nail | 1649 | Rear drag plate |
| 428 | Sound nail spring | 792 | Ball bearing (S624) | 1544 | M2.0 "E" washer | 1615 | Bearing cover | 1650 | Anti-reverse dog |
| 598 | Handle bolt washer | 921 | T handle nail | 1545 | Locking plastic ring | 1618 | Sound gear | 1652 | Drag plate |
| 601 | Washer 1 | 943 | Handle knob screw1 | 1546 | Sound nail spring | 1623 | Brake adjustment meson | 1653 | Sideplate (front) |
| 627 | Drag knob cover | 1147 | Handle cover | 1547 | Washer_0.1mm | 1624 | Spool shaft spring | 1656 | Spool |
| 630 | "O" ring | 1148 | Hander cover | 1548 | Washer_0.3mm | 1632 | Close cover | 1657 | Drag control lever |
| 646 | Pre-program key pin | 1151 | Lock set | 1549 | Washer_0.5mm | 1633 | Small tooth bushings | | |